

Saving the Running Configuration to the Startup Configuration

You can save the running configuration to the startup configuration to save your changes for the next time you that reload the device.

Procedure

	Command or Action	Purpose
Step 1	<p>show running-config</p> <p>Example:</p> <pre>show running-config</pre>	(Optional) Displays the running configuration.
Step 2	<p>copy running-config startup-config</p> <p>Example:</p> <pre>copy running-config startup-config</pre>	Copies the running configuration to the startup configuration. In effect, this saves the config so it persists after reboots.

Revision #3

Created 2023-11-11 09:47:21 UTC by Ryan

Updated 2025-02-12 01:10:57 UTC by Ryan